### **ELEKTRO PARTNER**

BULLETIN

MAKE / MODEL:

YEAR: 2017ENGINE CODE: All with SGW

Page 1 of 4

SUBJECT / SYMPTOM / TROUBLE CODE:

Delphi DS180 - Security Gateway (SGW) creation guide step 2 - Multiple users

### SOLUTION:

UK-10017

- 1. Start by pressing Log in if you are not already logged in, as in the example. It is important that it is the workshop manager who logs in
- 2. Invite the desired employee

etere Garway el <b>phi</b> cchnologie <del>s</del>		Dansk 🗸 Log	ud Date: 2023-07-21 Version: 11794	
Kontrolpanel		Kontrolpanel	1	
Profil		Profil		
Virksomhed	Q		Q.,	
Mærker	Navn		Rolle	
Indstillinger	ngskode		Ansvarshavende	
		Virksomhed		
		2	ନ୍ନ୍ନିନ	
	Navn Elektro Partner ApS	Ansvarshavende	Medarbejdere 0	
Vis virkse	nhed Inviter			

### Enter the email of the employee who is going to have access to Security Gateway unlocking. Press Send invitations.

₩ Secure Gateway Delphi Technologies	Dansk v Log ud Date: 2023-07-21 Veniere 11794
6 Kontrolpanel	Inviter
Profil Virksomhed	Belektropartner.dk Ttildj Send invitationer
C Mærker	
CCS mostiminger	





# **ELEKTRO PARTNER**

UK-10017

## BULLETIN

nvitation til si	<pre>ckerheds-gateway</pre>
NG noreply@	sgw.w-grp.net ⓒ ← Svar ← Svar til alle → Videresend fr 18-08-2023
Hvis der er problem	er med visningen af meddelelsen, kan du klikke her for at få vist den i en webbrowser.
	Kære modtager
	har inviteret dig til at blive en bruger af Security Gateway hos Elektro Partner ApS.
	For at fuldføre registreringen bedes du bruge aktiveringskoden "82b2242f-9031- 4ec1-810a-02da10be94b6" i brugerportalen. Du får adgang til siden ved at trykke på "Fået en invitation?" på tegnet på siden.
	Security Gateway
back to the D ss "Got an inv en enter the a may Mojes	elphi diagnostic tool. vitation?" ctivation code from the received email. Duck v 2010/21 Works 1194
back to the D ess "Got an inv en enter the a	elphi diagnostic tool. vitation?" ctivation code from the received email.
back to the D ess "Got an inv en enter the a	elphi diagnostic tool. vitation?" ctivation code from the received email.
back to the D ess "Got an inv en enter the a	elphi diagnostic tool. vitation?" ctivation code from the received email.
back to the D ess "Got an inv en enter the a array	elphi diagnostic tool. vitation?" ctivation code from the received email.
back to the D ess "Got an inv en enter the a orgen	elphi diagnostic tool. vitation?" civation code from the received email.
back to the D ess "Got an inv en enter the a or objes	elphi diagnostic tool. Vitation?" ctivation code from the received email.
back to the D ess "Got an inv en enter the a area alonges	elphi diagnostic tool. vitation?" citation code from the received email.
back to the D ess "Got an inv en enter the a area aloges	elphi diagnostic tool. <i>i</i> tation?" citvation code from the received email.
back to the D ess "Got an inv en enter the a	<complex-block></complex-block>





## ELEKTRO PARTNER BULLETIN

ŏ

### SOLUTION CONTINUED: Fill in the fields:

UK-10017

	Dansk Y Log ind Date: 2023-07-21	Version: 11794
Registrer medarbejder Elektro Partner ApS		
Log ind eller registrer en ny konto for at logge ind som medarbejder-		
Har du allerede en konto? Log ind her.		
* = obligatorisk felt E-mail *		
@elektropartner.dk		
Adgangskode *	0	
Adgangskoden skal indeholde mindst et stort bogstav, et lille bogstav, et tal, et specialt tegn	egn og have en længde på 12.	
Bekrett adgungskode *	TNER	
* Feitet skal afspejle din foretrukne identifikationsmetode (kørekort, pas. osv.)		
Efternavn *		
* Feltet skal afspejle din foretrukne identifikationsmetode (kørekort, pas. osv.)		
FordesIrdua *		
DD-MM-AAAA	<b>a</b>	
* Feltet skal afspejle din foretrukne identifikationsmetode (kørekort, pas, osv.)		
Telefon *		
Land *		
	×	

### Confirmation that registration is complete.

<b>Delphi</b> Technologies	Dansk V Log ud Demz 2023-07/21 Veniews 11794
Image: Control panel       Image: Control panel	Gennemført! Elektro Partner ApS Selektropartner.dk Medarbijdren bler registrent Kontolpart
	ELEKTRO







## **ELEKTRO PARTNER**

Page 4 of 4

ě

## BULLETIN

### SOLUTION CONTINUED:

#### Log in as the tester manager.

Under Companies (1) you can find Users (2) who are connected to the diagnostic tool. You can also see the role of the different users (manager/employee).

<section-header>Licrobic Debrow and a market of the second and</section-header>				Dantk v Log ud Dete: 2023-07-21 Veniee: 11794	
Nom Letto Patron Age   Absorbancedia Sind Absorbancedia   Absorbancedia Sind Absorbancedia   Absorbancedia Sind Absorbancedia   Madribiditaturare 0   Patronalistic   Nem Sind   Patronalistic   Variante Sind   Patronalistic   Variante Sind   Patronalistic   Nem Sind   Sind<	Image: Control of the state of th	Image: State		Virksomhed Elektro Partner ApS	
Nom       Bitto Patter AgS       By       Gindated         Accesshared a       By       Tindajevi         Mackadoder       Bitto Patter AgS       Bitto Patter AgS         Mackadoder       Bitto Patter AgS       Bitto Patter AgS       Bitto Patter AgS         Mackadoder       Tindajevi       Patterummer       7200         Mediatoder       Tindajevi       Bitto Patter AgS       Bitto Patterum Ags       B	Name Description     Name Description     Name Description     Norm     Norm    Norm Nor	n n     n <th></th> <th>Oslansijanar</th> <th></th>		Oslansijanar	
Meren big for VC. Konskt die sakykand for at tillige yderigere VC.re. Seiteummer VCl'er Rate to kan der kan tillige i der län tillige yderigere VC.re. Seiteummer * iswanneet dat aare på practs test tal	Andergine in the specific for the spe	Integrine		Navn         Bektro Partner ApS         By         Grindsted           Answarshewede         Vej         Techsjevej	
Nere	In a second seco	In the set of the set	Inviter	Administratore 0 Postnummer 7,00 Medarbojdere 1	
New 2 Relie of Section 2 Relie o	In the second se	In the second se			
Medite Control	line line line line line line line line	<form></form>	Navn	Brugere Rolle 3	Slet
Clier     A dette trin kan der kun tillgies der VCI. Kontakt din salgskanal for at tillgie yderligere VCTer.     Serlenummer     Handlinger     If of of		ELECTRON CARANTERS		Medarbejder	۱. ۱
VCI'er Pi dette trin kan der kun tillsjes én VCI. Kontakt din salgskanaf for at tillsje yderligere VCI'er. Serienummer Pindelinger C C C C C C C C C C C C C C C C C C C	VCI e martine una traduction and and and and and and and and and an	VCr I IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII	Inviter		
Serienummer Handlinger	interent of the set o	Image: The provide of the state of the s	<b>VCI'er</b> På dette trin kan der kun tilføjes én VCI. Kontakt din salgs	gskanal for at tilfsje yderfigere VCTer.	
Title		* a main	Serienummer	Handlinger rg? Dil	
	**eeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeee	**eeste take ang ju pates test.	Tiffej		
	Marker  He due due due due due due due due due du	Merker  In da administrere, hike bande du el akterer og bækterer for div vikasenete	* Serienummeret skal være på præcis seks tal.		
Mærker Her kan du administrere, hvilke brands du vil aktivere og deaktivere for din virksomhed			Mærker Her kan du administrere, hvilke brands du vil aktivere og	a deatoiree for din virksomhed	

